



## ADDITIVE MANUFACTURING

This tutorial shows how to open the AM template, select a printer, mount a part onto the AM build tray, subject the part to AM checkers, generate supports, modify support attributes and generate/prepare the part file for printing




## OPEN AM TEMPLATE

1. In NX, on the **Ribbon bar** in the **Home** tab, select **New**
2. In the **New** dialog box, select **Additive Manufacturing**, enter a name for the part file, (default additive\_manufacturing1.prt) then click **OK**




## SELECT PRINTER

1. **Select 3D Printer** dialog box prompts to select a type of printer from the available list. Upon selection, click **OK**




**Notice** the selected build tray (printer) appears in the graphics window




## ADD COMPONENT

1. To add a component to the build tray, in the **Additive Manufacturing Navigator** menu, right click on the printer in the **Build Tray** group, from the drop-down menu, select **Add Component**



OR


In the Ribbon bar, under the **Home** tab, click on **Add**



2. In the **Add Component** dialog box, click on **Open**  icon to browse for the part "**Simple\_Cantilever\_result**" in the stored folder  
**Notice** the selected part appears on the build tray in the graphics window  
**NOTE:** Multiple parts can be selected
3. Enter the desired number of copies of the selected part (or parts) under the **Count** list. Enter **Count = 1**
4. Specify desired **Location** of the part  
**Component Anchor = Absolute**  
**Assembly Location = Absolute – Work Part**  
**Cycle Orientation = WCS** 
5. Specify the **Placement** of the part  
**Placement = Move**

Click **OK**

**Notice** the component mounted on the build tray in the graphics window



## **DESIGN VALIDATION FOR ADDITIVE MANUFACTURING**


Part (or parts) mounted on the build tray must satisfy some AM checkers-

### **PRINTABLE VOLUME**

The **Printable Volume** checker helps determine the size of build tray required for a part positioned in a specified orientation.


The test results in- passed,  failed  or passed with a warning 

1. On the Ribbon bar, in the **Analysis** tab, click on **Printable Volume**




2. In the **Check Printable Volume** dialog box, **Select Body** from the graphics window
3. In the **Volume Display** group, select **Show = Both** to visualize both Printable Volume and Product Volume
4. Hover mouse over the  symbol either in the graphics window or in the **HD3D Tools** navigator on the **Resource bar** to see information about test results


**Notice** in the graphics window, the result of Printable volume test



5. As the part dimensions exceed the build tray dimensions, the test has failed. Therefore, either the part can be repositioned to fit into the printer or a different printer can be selected  
**NOTE:** Re-positioning the part may compromise with optimum build orientation; the build height and hence the build time and consequently the build cost may increase. Therefore, in this case, assuming that the default orientation is the optimum orientation, we select a different printer
6. In the **Additive Manufacturing Navigator** menu, in the **Build Tray** group, right click on the printer, then click on **Select 3D Printer**. In the **Select 3D Printer** dialog box, choose a printer from the list




**Notice** the part mounted on a different printer



7. Check once again for **Printable Volume**
8. Hover mouse over the  symbol either in the graphics window or in the **HD3D Tools** navigator on the **Resource bar** to see information about test results

**Notice** the part has now passed the **Printable Volume** checker.




9. Close the **Check Printable Volume** dialog box

### **WHOLLY ENCLOSED VOLUME**

The **Wholly Enclosed Volume** checker checks for support requiring areas on the part that are entirely enclosed by other regions in a solid body. This test results in either passed  - No enclosed volumes or failed  - At least one enclosed volume

1. On the Ribbon bar, in the **Analysis** tab, click on **Wholly Enclosed Volume**
2. In the **Check Wholly Enclosed Volume** dialog box, select body from the graphics window
3. In the Resource bar, hover mouse over the  symbol to check result in the **HD3D Tools** navigator, under **Results** tab

**Notice** the result status for **Wholly Enclosed Volume** is passed



4. Close the **Check Wholly Enclosed Volume** dialog box

## WALL THICKNESS

The **Wall Thickness** checker checks the minimum wall thickness of the model for Additive Manufacturing. The test results are displayed graphically into highlighted areas on the part that are more than and less than the Minimum Thickness

More than Minimum Thickness




Less than Minimum Thickness



1. On the Ribbon bar, in the **Analysis** tab, click on **Wall Thickness**
2. In the **Check Minimum Wall Thickness** dialog box, select the body from the graphics window
3. **Notice** in the **Thickness** group, the default value for **Minimum Thickness** is 0.4. Keep the **Show Only Less than Minimum Thickness** box unchecked
4. In the **Process Results** group, click **Calculate Thickness**  to display results

**Notice** the areas less and more than the minimum thickness highlighted on the part




5. Close the **Check Minimum Wall Thickness** dialog box

## **MINIMUM RADII**


The **Minimum Radii** checker checks the minimum radii of the model for Additive Manufacturing. The test results are displayed graphically into highlighted areas on the part that are more than and less than the Minimum Radius

1. On the Ribbon bar, in the **Analysis** tab, click on **Minimum Radii**
2. In **Check Minimum Radii** dialog box, select the body from the graphics window
3. **Notice** in the **Radius of Curvature** group, the default value for **Minimum Radius** is 0.5. Keep the **Exclude Convex Radii** and **Show Only Less than Minimum Radius** boxes unchecked
4. Select from drop-down menu whether the results are to be displayed in **3D Minimum** mode or **Sectional** mode

Notice the results in **3D Minimum** mode



Notice the results in **Sectional** mode



5. Close the **Check Minimum Radii** dialog box


## OVERHANG ANGLE

The **Overhang Angle** checker calculates and displays the area requiring supports on a part positioned in a specified orientation. The test results are displayed graphically into highlighted areas on the part less than and greater than the Maximum Overhang angle including Extended Angular Tolerance

Less than Maximum Overhang Angle	
More than Maximum Overhang Angle	
Exceeding Extended Tolerance	

1. On the Ribbon bar, in the **Analysis** tab, click on **Overhang Angle**
2. In **Check Maximum Overhang Angle** dialog box, select the body from the graphics window
3. In the **Angle** group, **notice** that the **Maximum Overhang Angle** is 45 degrees. Check the **Show Only Exceeding Overhang Angles** box


**Notice** in the **Overhang Area** group, the area requiring supports is displayed as a numeric value 2360.376959 mm<sup>2</sup> and the areas are highlighted on the part in the graphics window




4. Close the **Check Maximum Overhang Angle** dialog box

# CREATE AUTOMATIC SUPPORTS

1. For automatic support generation, in the **Additive Manufacturing Navigator** menu, right click on the part in the **Build Tray** group, from the drop-down menu, select **Create Automatic Supports**




**Notice** the block supports generated in the **Additive Manufacturing Navigator** menu and on the part in the graphics window



## SUPPORT ATTRIBUTES

1. To edit support attributes, select a support block on the part in the graphics window. **Notice** the selected block-name highlighted in the **Additive Manufacturing Navigator** menu, in the **Build Tray** group  
**NOTE:** The generated Block name of selected support block could change the next time automatic supports are generated on the same part

**Notice** the selected support block in the graphics window



2. In the **Support Attributes** group, change the support attribute values as shown for the selected support block


**Angled Support = True**

**Shift Y = -10.0000**

**Perforations = True**

**NOTE:** Set the **Perforations** 'True' twice- for perforations both inside the support block volume and for perforations on the block border

## Notice the support attribute values in the graphics in the **Additive Manufacturing Navigator**





3. After changing the values, click on **Regenerate**  to regenerate support


4. To copy attributes of one support block onto another, in the **Build Tray** group-

- Right-click on the support block and select **Copy Attributes**
- Now, in the desired support block, right-click and select **Paste Attributes**

**NOTE:** Attributes can be pasted into multiple support blocks (multi-select using **Shift** button)




**Notice the change in support blocks**



## **ASSIGN BUILD STRATEGY**

The printer needs to be assigned a build strategy; like setting certain machine parameters, material, slice profile, etc. Build strategies can be configured in the Build Processor manager of **Materialize**. For this tutorial, we use a demo build processor with a default build strategy

1. To assign a build strategy, in the **Additive Manufacturing** navigator, in the **Build Tray** group, right-click on the printer. From the list, select **Edit Build Strategy**




2. In the **Edit Build Strategy** dialog box, set each column to **Default**



## **3D PRINTER**

Now that the support structures are generated, build strategy is defined, the part is ready to be sent for printing. On the Ribbon bar, in the **Home** tab, under **3D Printer** group, click on each icon-

1. **GENERATE**: To send the part file for pre-processing printer specific files, click on **Generate**
2. **PRINT**: To queue the job file for building into the printer, click on **Print**
3. **OPEN SLICE VIEWER**: To view all the slices and hatch pattern on each layer of the printer job file, click on **Open Slice Viewer**



**Notice the hatch pattern on the slice**

